



Berkey[®]
WATER SYSTEMS

Sport Berkey[®] Water Filter Bottle



The unique **Sport Berkey**[®] filter is made from a proprietary blend of media, and is backed by independent third-party testing.

Test results showed up to a 99.9% reduction for typical contaminants found in water, such as:

- Heavy metals • Herbicides
- Pesticides • Pharmaceuticals
- Organic chemicals
- Petroleum-based products
- Sediment • Silt
- Unpleasant tastes and more

Precautions

- To prevent leaks, do not store filled bottle on its side or upside down.
- Do not allow filter to freeze.
- Do not place bottle or filter in dishwasher or microwave oven.
- Do not run hot water through filter.
- Make sure straw is clean before using. If straw is dirty, or if you suspect that the straw is dirty, reclean the straw before use (see cleaning instructions on next page).

Specifications

- Capacity: 22 oz. (0.6 L)
- 50 year shelf life
- We recommend replacing the filter after 640 refills of municipal water or 160 refills of untreated freshwater sources. Filter may require replacement sooner based upon the quality of influent water.

Warranty Information

The **Sport Berkey**[®] water filter bottle is covered by the NMCL Limited Warranty: 6 Months. Warranty coverage begins the date product is received.

Usage & Storage



IMPORTANT! Flush Filter Before Use

Flushing clears excess carbon from the manufacturing process.

1. Pull lid closure down so that straw is exposed.
2. With bottle full of water, squeeze the bottle for 3-4 seconds to flush water through filter and straw.
3. **Repeat until water runs clear.**
4. Bottle is ready to use.

Using Your Bottle

1. Fill the **Sport Berkey®** water filter bottle with water.
2. Screw on lid and tighten securely to prevent leaks.
3. To drink: pull lid closure down to expose straw. Squeeze bottle to squirt water out of straw into mouth, or suck water through straw, or use both actions together.
4. To close: simply pull lid closure up to conceal straw (this helps prevent drips or leaks while carrying).



Replacing the Filter

We recommend replacing the filter after 640 refills of municipal water. Filter may require replacement sooner based upon the quality of influent water.

1. Unscrew lid from bottle.
2. Pull existing filter from straw.
3. Push new filter onto straw.
4. Flush new filter before using (see above for instructions).

Cleaning and Storage

Periodically remove straw filter element and clean the bottle and straw with warm water and mild, unscented dish soap.

If straw filter element will not be used for an extended period of time:

1. Remove filter from straw and allow to air dry.
2. Once filter is dry, place it back on straw inside bottle.